

MODELLO BASE - ISTRUZIONI

BASE MODEL - INSTRUCTIONS

MODÈLE BASE - INSTRUCCIONES

BASISMODELL - INSTRUCTIONEN





MOD. A1

Place the vaporizer on a solid, flat and stable surface. Plug in and push the button "POWER". Check that a propolis capsule is in place. Lighting up of led number 1 and a sound indicate that the vaporizer is now on and that the heating of the capsule has started.

Consecutive lighting of the green leds, i.e. digits 1 to 6, correspond to about 21 hours of propolis vaporization. It is possible to manually switch the vaporizer ON and OFF to suit the needs of the user who may operate the vaporize by pressing the POWER button.

The capsule is disposable and has a duration of about 122 hours.

A simultaneous flashing of all the green leds and a beep sound every five seconds, indicate that the full cycle for the one capsule has come to an end. At this point in time the "POWER/RESET" button must be pressed for about 10 seconds till all green leds are lit. The spent capsule must now be replaced with a fresh one to restart the heating cycle.

NB. DO NOT REPLACE THE CAPSULE BEFORE THE TERMINATION OF THE FULL CYCLE.

In order to obtain the best possible results in the prevention of respiratory ailments and for the full sanitation of secluded places, KONTAK recommends the use of the vaporizer 24hrs a day.

MOD. A2 WITH IONIZER

Place the vaporizer on a solid, flat and stable surface. Plug in and push the button "POWER". Check that a propolis capsule is in place. Lighting up of led number 1 and a sound indicate that the vaporizer is now on and that the heating of the capsule has started.

Consecutive lighting of the green leds, i.e. digits 1 to 6, correspond to about 21 hours of propolis vaporization. It is possible to manually switch the vaporizer ON and OFF to suit the needs of the user who may operate the vaporize by pressing the POWER button.

The capsule is disposable and has a duration of about 122 hours.

A simultaneous flashing of all the green leds and a beep sound every five seconds, indicate that the full cycle for the one capsule has come to an end. At this point in time the "POWER/RESET" button must be pressed for about 10 seconds till all green leds are lit. The spent capsule must now be replaced with a fresh one to restart the heating cycle.

NB. DO NOT REPLACE THE CAPSULE BEFORE THE TERMINATION OF THE FULL. CYCLE.

In order to obtain the best possible results in the prevention of respiratory allments and for the full sanitation of secluded places, KONTAK recommends the use of the vaporizer 24hrs a day.

The ionizer is activated when the vaporizer is plugged in, irrespective of the POWER button.

MOD. A2 WITH IONIZER AND FAN 😂 🤻

Place the vaporizer on a solid, flat and stable surface. Plug in and push the button "POWER". Check that a propolis capsule is in place. Lighting up of led number 1 and a sound indicate that the vaporizer is now on and that the heating of the capsule has started.

Consecutive lighting of the green leds, i.e. digits 1 to 6, correspond to about 21 hours of propolis vaporization. It is possible to manually switch the vaporizer ON and OFF to suit the needs of the user who may operate the vaporize by pressing the POWER button.

The capsule is disposable and has a duration of about 122 hours.

A simultaneous flashing of all the green leds and a beep sound every five seconds, indicate that the full cycle for the one capsule has come to an end. At this point in time the "POWER/RESET" button must be pressed for about 10 seconds till all green leds are lit. The spent capsule must now be replaced with a fresh one to restart the heating cycle.

NB. DO NOT REPLACE THE CAPSULE BEFORE THE TERMINATION OF THE FULL CYCLE.

In order to obtain the best possible results in the prevention of respiratory ailments and for the full sanitation of secluded places, KONTAK recommends the use of the vaporizer 24hrs a day.

The ionizer is activated when the vaporizer is plugged in, irrespective of the POWER button. The fan mode may be activated by pressing for 5 seconds the "POWER" button while the vaporizer is "ON". Each time the vaporizer is switched OFF the fan mode is disactivated.

