

## WARRANTY

The manufacturer's warranty has a duration of 24 months. It covers replacement or free repair of the defective part as confirmed by the dealer or by a third person appointed by the dealer.

The warranty becomes null and void if the diffuser is not properly used according to the instructions of the manufacturer. It is equally null and void should the diffuser be modified, repaired or disassembled outside the premises and control of the dealer.

### TECHNICAL CHARACTERISTICS:

**Voltage: 110 V**  
**Alternating current : 60 Hz**  
**Dimension: 170 x 140 x 50**  
**Weight: 1,000 Kg**

The system is patented. N° IT 01240474



## "PROPOLINA" DIFFUSER

with Ionizer ○



**INSTRUCTIONS**



## INSTRUCTIONS

Place the diffuser on a flat surface, insert wings and antennae in the appropriate inserts, plug in and press the "Power" button.

Lighting up of antennas, together with a sound, indicate that the diffuser is now on and that the heating of the capsule has started.

Consecutive lighting of the 2 green antennas, correspond to about 20 hrs of capsule heating per digit.

The end of the cycle of the capsule is indicated by the simultaneous flashing of the two antennas and a beep every 5 seconds

**At this point, with the diffuser turned on, press the "POWER" button for about 12/15 seconds (you will hear a**

**continuous beep before and then an alternating), then replace the expended capsule with a new one in order to start a new cycle.**

The capsule is disposable and has a duration of approximately 122 hours.

Example of use:

- when using the diffuser 8 hours a day, the capsule lasts about 15 days ( $122: 8 = 15$ ).
- when using the diffuser 24 hours a day, the capsule lasts about 5 days ( $122: 24 = 5$ ).

### ***Propolina with Ionizer:***

The ionizer is turned on and off when inserting the plug and is independent of the "POWER" button

**NEVER REPLACE THE CAPSULE BEFORE THE END OF THE CYCLE.**

For best results in the prevention of respiratory diseases and for a complete environmental sanitisation, KONTAK recommends the use of 24-hour 24

**DO NOT REMOVE FOR ANY REASON THE STICKER**